BRICK

SAW CUT REGLET ½" - 1" DEEP, BLOW OUT DUST
& FILL WITH SIKAFLEX SEALANT. SET FLASH &
FASTEN WITH COMPATIBLE MASONRY ANCHOR.

2" FASTENER @ EVERY
MAIN RIB OR 12" C/C MAX.

ENDWALL FLASHING

BUTYL SEALANT TAPE TOP &
BOTTOM OF CLOSURE

OUTSIDE CLOSURE

ROOF PANEL

ICE AND WATER SHIELD

ROOF STRUCTURE

CHIMNEY ENDWALL DETAIL